
# week 02

# **Physical Computing**

#### Bridging the gap between the physical and virtual

# How the Computer Sees Us

Shall we take a better look at ourselves to see our full range of expression?



# **Physical Computing**

A conversation between the physical world and the virtual world of the computer.



# **Physical Computing**

A conversation between the physical world and the virtual world of the computer.




# Input and Output

Ways of sensing your physical energy/expressions. Input is usually easier than output because it takes less energy to sense activity than to move things.




# Input and Output Output

Physical computing is not just about sensing the world, but also about changing it. But moving things are hard (you need electrical and mechanical skills).



#### **Transducers**




6

#### **Microcontrollers**


#### Gateway between the physical and the virtual

 Receiving information from sensors,
 controlling basic motors and other devices that create physical change, and
 sending information to computers and other devices.



8

#### **Transduction**



input transducers

9

# **Digital and Analog**

#### **Digital signal**

Difference between two possible states

"whether or not"

Is the cat on the mat or not?

#### Analog signal

continuous range of possible states

"how much" or "stronger" "faster" "brighter"

How heavy is the cat that's on the mat?

#### Word of Caution: Your Idea is Important

- 1. Don't get trapped in technological seduction
- Don't spin your wheels for so long that you give up your project. There might be an alternative way that makes things easier.
   Work at a high level. Talk to us. Ask other people. Take frequent breaks.


# **Working with Arduino**

#### An open-source electronics prototyping


Create interactive objects and environments

#### What is Arduino


A tiny computer you can program, for rapid prototyping




#### **Arduino as an Interface Board**



#### **Arduino as an Interface Board**




#### Arduino as an Embedded Computing Device



16

#### What is Arduino

#### Relatively cheap (compare with LEGO Mindstorm)



#### What is Arduino

It used to be a bit more complicated...





image from www.tangentsoft.net/elec/breadboard.html




HOW TO - Make an aux-in for the Bose SoundDock Last Day of the Weekend Subscribe to the Weeken Projects Podcas

#### Barebones Arduino on a breadboard




Here is a truly barebones Arduino setup. Just the Arduino chip and a few support parts. This has to be close to the simplest and lowest cost way to play with microcontrollers. The only special parts are the resonator and the Mega168 programmed with the Arduino boot loader. Everything else you should already have as an electronics hobbyist.


# Open source, so you can build one yourself!




- 16 kBytes of Flash program memory (your program stays in Arduino when powered off)
- 1 kByte of RAM
- 12 MHz (Apple II: 1 MHz) processor speed




- 13 digital input/output pins
- 5 analog input pins





• USB to serial chip (converts simple serial signal to USB)



#### Arduino Software www.arduino.cc

#### Arduino

Buy | Download | Getting Started | Learning | Reference | Hardware | FAQ

Blog » | Forum » | Playground »

search



Photo by Nicholas Zambetti

#### Arduino News (archive)

2008.09.03 Arduino.cc on the move!! During the next week we will migrate all our online services to a new and better server, we apologize for eventual cuts while in the process.

2008.07.11 New distributors: <u>Robotev</u> in Bulgaria and <u>Linux</u> <u>Center</u> in Russia. Full list on the <u>buy</u> page.

2008.05.17 New Hardware: Arduino Nano available for preorder, by Gravitech. Shipping June 16.

2008.04.29 Check out: Mecharoboshop, our latest distributor in Japan Arduino is an open-source electronics prototyping platform based on flexible, easy-to-use hardware and software. It's intended for artists, designers, hobbyists, and anyone interested in creating interactive objects or environments.

Arduino can sense the environment by receiving input from a variety of sensors and can affect its surroundings by controlling lights, motors, and other actuators. The microcontroller on the board is programmed using the Arduino programming language (based on Wiring) and the Arduino development environment (based on Processing). Arduino projects can be stand-alone or they can communicate with software on running on a computer (e.g. Flash, Processing, MaxMSP).

The boards can be <u>assembled by hand</u> or <u>purchased</u> preassembled; the software can be <u>downloaded</u> for free. The hardware reference designs (CAD files) are <u>available</u> under an open-source license, you are free to <u>adapt them to your</u> needs.

Arduino received an Honory Mention in the Digital Communities section of the 2006 Ars Electronica Prix. Credits

#### Buy an Arduino Board

Download the Arduino Software

#### Getting Started


To get started, follow the instructions for your operating

### **Arduino Software**


📳 Arduino - 0008 Alpha		
File Edit Sketch Tools Help		
de l'éte		
Blink		₽
/*		
* Blink		
* * The besic Arduing evennle	Turns on an LED on for one second,	
	iurns on an LED on for one second, i so on We use pin 13 because,	
	pard, it has either a built-in LED	
* or a built-in resistor so th	nat you need only an LED.	
*		
<pre>* http://www.arduino.cc/en/Tut */</pre>	torial/Blink	
*Z.		
<pre>int ledPin = 13;</pre>	// LED connected to digital pin 13	
void setup()	// run once, when the sketch starts	
<pre>{     pinMode(ledPin, OUTPUT);</pre>	// sets the digital pin as output	
}	// SELS die digital pin as suspac	
<pre>void loop()</pre>	// run over and over again	
{		
<pre>digitalWrite(ledPin, HIGH); delew(1000);</pre>		
delay(1000); digitalWrite(ledPin, LOW);	// waits for a second // sets the LED off	
delay(1000);	// waits for a second	
}		
<		>
Done compiling.		
Binary sketch size: 1108 b <del>y</del> tes	(of a 14336 b <del>y</del> te maximum)	

#### **Arduino Sketches**


👫 Arduino - 0008 /	Alpha					
File Edit Sketch To	ols Help					
New	Ctrl+N	1				
Sketchbook	•	Open	Ctrl+O			
Save	Ctrl+S	arduino-0008-win	•			₽
Save As	Ctrl+Shift+S	Kimiko Sketching	•			^
Upload to I/O Board	Ctrl+U	processing-0124				
Page Setup	Ctrl+Shift+P	sketch_070811a				
Print	Ctrl+P	sketch_070811b		for one second,		
Preferences	Ctrl+,	sketch_070813a		in 13 because,		
Quit	Ctrl+Q	sketch_070819a		a built-in LED		
*		Examples	•	Analog	×	
* http://www.arduino.cc/en/Tutorial/Blink			Communication	Ы		
*/				Digital	•	Blink
				Library-EEPROM	•	Button
<pre>int ledPin = 13;</pre>		// LED conn	ected	Library-Matrix		Loop
void setup()		// run once	rrhon	Library-SoftwareSerial	М	
() () () () () () () () () () () () () (		// run once	, wrien	Library-Stepper	비	
pinMode(ledPin,	OUTPUT);	// sets the	digit.	Library-Wire		
}			-			
<pre>void loop()</pre>		// run over	and or	7er again		
{	dDin UTCU	· // acta the	IFD or			
<pre>digitalWrite(le     delay(1000);</pre>	eurin, <mark>nich</mark>	); // sets the // waits fo				
	edPin, <mark>LOW</mark> ).	; // sets the				





File Edit Sketch Tools Help		
00 DYV01		
Blink		₽
/*		
* Blink		
* * The beside budgets around be	There are a TED on few means and	
	Turns on an LED on for one second, i so on We use pin 13 because,	
	pard, it has either a built-in LED	
* or a built-in resistor so the	hat you need only an LED.	
* * http://www.arduino.cc/en/Tu	news all (Tallian)	
*/	coriai/blink	
<pre>int ledPin = 13;</pre>	// LED connected to digital pin 13	
void setup()	// run once, when the sketch starts	
(		
	// sets the digital pin as output	
}		
void loop()	// run over and over again	
(		
<pre>digitalWrite(ledPin, HIGH); delay(1000);</pre>	// sets the LED on // waits for a second	
digitalWrite(ledPin, LOW);		
delay(1000);	// waits for a second	
}		
(		>
		<u>~</u>
Done compiling.		
Binary sketch size: 1108 bytes	(of a 14336 byte maximum)	
Sinary Sketch Size. 1108 bytes	(or a 14000 byce maximum)	




Blink		
* Blink		
*		
	Turns on an LED on for one second,	
	d so on We use pin 13 because,	
* depending on your Arduino b * or a built-in resistor so t	oard, it has either a built-in LED	
*	nac you need only an mer.	
* http://www.arduino.cc/en/Tu	torial/Blink	
*/		
int ledPin = 13;	// LED connected to digital pin 13	
10, 10111 10,	)) her connected to argreat pin 10	
void setup()	// run once, when the sketch starts	
{		
	<pre>// sets the digital pin as output</pre>	
}		
void loop()	// run over and over again	
{		
digitalWrite(ledPin, HIGH);		
<pre>delay(1000); digitalWrite(ledPin, LOW);</pre>	// waits for a second	
digitalwrite(ledrin, LOW); delay(1000);	// sets the LED OII // waits for a second	
<pre>delay(1000); }</pre>	// Warts for a second	
,		
<		
Done compiling.		











Watch your LED blink!

## **Arduino Program**

Program consists of 3 parts:

1. Declare variables at top

#### 2. Initialize

setup() - run once at beginning, set pins

#### 3. **Run**

loop() - run repeatedly, after setup()

# **Arduino Language**

Like C but easier

**Example functions** 

- pinMode() set a pin as input or output
- digitalWrite() set a digital pin high/low
- digitalRead() read a digital pin's state
- analogRead() read an analog pin
- analogWrite() write an "analog" PWM value
- delay() wait an amount of time

#### **Example** (and many other examples at www.arduino.cc)

```
/#
 * Blink
 *
 * The basic Arduino example. Turns on an LED on for one second,
 * then off for one second, and so on... We use pin 13 because,
 * depending on your Arduino board, it has either a built-in LED
 * or a built-in resistor so that you need only an LED.
 *
 * http://www.arduino.cc/en/Tutorial/Blink
 */
int ledPin = 13;
                                // LED connected to digital pin 13
void setup()
                                // run once, when the sketch starts
{
  pinMode(ledPin, OUTPUT);
                               // sets the digital pin as output
}
void loop()
                                // run over and over again
£
  digitalWrite(ledPin, HIGH);
                               // sets the LED on
  delay(1000);
                                // waits for a second
  digitalWrite(ledPin, LOW);
                               // sets the LED off
  delay(1000);
                                // waits for a second
3
```

#### Example (and many other examples at www.arduino.cc)

```
/#
 * Blink
 *
 * The basic Arduino example. Turns on an LED on for one second,
 * then off for one second, and so on... We use pin 13 because,
 * depending on your Arduino board, it has either a built-in LED
 * or a built-in resistor so that you need only an LED.
 *
 * http://www.arduino.cc/en/Tutorial/Blink
 */
                                                                                  Declare variables
int ledPin = 13;
                                // LED connected to digital pin 13
                                // run once, when the sketch starts
void setup()
{
  pinMode(ledPin, OUTPUT);
                               // sets the digital pin as output
}
void loop()
                                // run over and over again
£
                               // sets the LED on
  digitalWrite(ledPin, HIGH);
  delay(1000);
                                // waits for a second
  digitalWrite(ledPin, LOW);
                               // sets the LED off
  delay(1000);
                                // waits for a second
3
```

#### Example (and many other examples at www.arduino.cc)


```
/#
 * Blink
 *
 * The basic Arduino example. Turns on an LED on for one second,
 * then off for one second, and so on... We use pin 13 because,
 * depending on your Arduino board, it has either a built-in LED
 * or a built-in resistor so that you need only an LED.
 *
 * http://www.arduino.cc/en/Tutorial/Blink
 */
int ledPin = 13;
                                // LED connected to digital pin 13
                                                                                  Initialize
                                // run once, when the sketch starts
void setup()
{
 pinMode(ledPin, OUTPUT);
                                // sets the digital pin as output
}
void loop()
                                // run over and over again
£
  digitalWrite(ledPin, HIGH);
                               // sets the LED on
  delay(1000);
                                // waits for a second
  digitalWrite(ledPin, LOW);
                               // sets the LED off
  delay(1000);
                                // waits for a second
3
```

Run


#### Example (and many other examples at www.arduino.cc)


```
1#
 * Blink
 *
* The basic Arduino example. Turns on an LED on for one second,
* then off for one second, and so on... We use pin 13 because,
* depending on your Arduino board, it has either a built-in LED
* or a built-in resistor so that you need only an LED.
 *
 * http://www.arduino.cc/en/Tutorial/Blink
 */
int ledPin = 13;
                               // LED connected to digital pin 13
void setup()
                                // run once, when the sketch starts
{
 pinMode(ledPin, OUTPUT);
                              // sets the digital pin as output
}
void loop()
                                // run over and over again
{
 digitalWrite(ledPin, HIGH);
                              // sets the LED on
  delay(1000);
                               // waits for a second
 digitalWrite(ledPin, LOW);
                              // sets the LED off
  delay(1000);
                               // waits for a second
```


### **Arduino and Breadboard**



## **Arduino and Breadboard**








#### **Solderless Breadboard**


-	1	1	1	i.	-		13	13	17	1	ł	-	-	12	1	-	-	57	1	100	-	3	1970	0	-	22	1	1	22	10.5	2	-		11	ξť.		2		10	a	12.1	2.3	-		*	-	0		*	-	
-	-19.2	-	194	-	-		13.4	10.1	5.7		5	- 70	120	10	200			- 2		25	-	.3	-	5 70	10	2		. 10	-	19.2	1	-	-	2.2	20		-	DE E	10					1							
-	1		10	-		•		2			1	11					R	1	1		-				8	-			33			0	4		10	-	\$				8				18						
7.3	1	I				н.	1		1.1	2	2	1		7	*	•							2						Υ.		92	-	2								•					5.5		2		1	
TR	1.			T	a.	×.	21		1.1		ť,h	1			1	7		18	17	10		•	1.5	1.31		111	• •		1	1.0	1.74	1						•		۰.	TO 3	r. T			1		Ŧ	•		*	ł
					-						Į,			-				ł.										1 M				10							-					+		1	+	4		+	8
 					-				in.			1 iu				'n					5	in.						nu.					1		02	-			66										22		
	1.14	1	i in	1	-	4		•	•	•		1		1	*	τ.)	•	• •		14		1.5		1		*			*13	1.7		*	*	r v	4			i ar	*	71.1	1.4	*	۳	* *		( W	٣	* *	-	*	1
				1	1	T				1			1			•	1	18	T	10	1	•	1		1				-		1		1		-	-			-		1.1	-				-		.,			,
 58		1	1	1	10	ę.						2	12	1	8	1		1	1	2			1		8	8	16	1		15	12	88		18	8			10	2					11			÷	11			ļ
	10		10		1	3	1							1		1	1			2	1						12	1		1	1		1		1	-	44		1				•	1.7	a.		•			1	t
-				÷				2				-	11			ii s	2				10				R				11				2			-	2			6	ŧ.			-	1			8			
÷	1	e) 14	1.3	1.6	10		8	Ξ.	8)	8.1	6.	1	12	8	8	Н.	1	11	8	H	В	3	1	8	8	8	-12	-	8	18		1	88	B	H.		1 1	H	8.8	в.,	10	5	3	1.5		11	21	1			-

41

#### **Solderless Breadboard**




#### **Solderless Breadboard**




## **Circuits: Avoid Shortcuts**

Electricity always favors the path of least resistance to ground




## **Circuits: Avoid Shortcuts**

Electricity always favors the path of least resistance to ground






#### All the electrical energy in a circuit must be used



#### LED

- LED = Light-Emitting Diode
- Needs a "current limiting" resistor, or burns out



## **Circuits Summary**

Avoid deadly shortcuts

- Flows to the lowest resistance
- All the electrical energy in a circuit must be used

When in doubt, talk to us, we can help


(Your Arduino has some fail safe, but in the worst case, you could fry your board [\$33.00])

## Try to be Neat


Color code:

- Red: power
- Black: ground

Be consistent




Good



Bad

#### **Be Careful**




## **Lab Assignment This Week**

- Get the course lab kit
- Download & install Arduino software (www.arduino.cc)
- Make an LED blink
  - Make it blink at different rate
- Create your course web account
- Post the photo of your board and an optional comment on the course website

### Lab Assignment: Blinking LED

#### 1# \* Blink $^{\star}$ \* The basic Arduino example. Turns on an LED on for one second, \* then off for one second, and so on... We use pin 13 because, \* depending on your Arduino board, it has either a built-in LED \* or a built-in resistor so that you need only an LED. \* \* http://www.arduino.cc/en/Tutorial/Blink #/ int ledPin = 13; // LED connected to digital pin 13 void setup() // run once, when the sketch starts { pinMode(ledPin, OUTPUT); // sets the digital pin as output 3 void loop() // run over and over again Ł digitalWrite(ledPin, HIGH); // sets the LED on delay(1000); // waits for a second digitalWrite(ledPin, LOW); // sets the LED off delay(1000); // waits for a second з




#### Your assignment looks like this





220 ohm resistor red, red, brown, gold Polarity does not matter



## **Next Thursday**

Don't forget to bring your lab kit in Do use the lab hour to catch up Create your course account Post your assignemtn on the course website

# **Thanks!**